

## REPLACEMENT

### AXKT

Replacement for any damaged or lost sensor. For use with models listed below \*

### SPECIFICATIONS

**Dimensions:** (Inside Diameter) .50"; (Outside) 2.05" x 1.46" x 1.50"

**\*Only For Use With:** RIBXLCRA, RIBXLCRF, RIBXLSRA, RIBXLSRF, RIBXRA, RIBXRF

**Purpose:** Can replace any damaged or lost sensor. For use with the models listed above.

