

### To set time and day

- 1 Press SET CLOCK/DAY/SCHEDULE\*
  - 2 Press ▲ / ▼ to set time
  - 3 Press SET DAY
  - 4 Press ▲ / ▼ to select day
  - 5 Press Done to save & exit
- \*If this option is not displayed, press DONE, RUN SCHEDULE or CANCEL

### To set program schedule

- 1 Press SYSTEM to select Heat or Cool
- 2 Press SET CLOCK/DAY/SCHEDULE\*
- 3 Press SET SCHEDULE
- 4 Press ▲ / ▼ to set the Wake time, then press NEXT
- 5 Press ▲ / ▼ to set the Wake temperature, then press NEXT
- 6 Repeat steps 4-5 to set Leave/Return/Sleep time periods
- 7 Repeat steps 4-6 to set time periods for other days
- 8 Press DONE to save & exit

### To override program schedule

- Press ▲ / ▼ to change temp for this time period only
- Press HOLD, ▲ / ▼ to change temp for all time periods
- Press RUN SCHEDULE or CANCEL to resume program

Copyright © 2012  
Honeywell International Inc.  
All rights reserved.  
P.B. Rev. 08-12



69-1778ES-04

### Para ajustar el día y la hora

- 1 Oprima SET CLOCK/DAY/SCHEDULE\*
  - 2 Oprima ▲ / ▼ para ajustar la hora
  - 3 Oprima SET DAY
  - 4 Oprima ▲ / ▼ para ajustar el día
  - 5 Oprima Done para salir
- \*Si esta opción no aparece, oprima DONE, RUN SCHEDULE o CANCEL

### Para fijar el programa de horarios

- 1 Oprima SYSTEM para seleccionar Heat o Cool
- 2 Oprima SET CLOCK/DAY/SCHEDULE\*
- 3 Oprima SET SCHEDULE
- 4 Oprima ▲ / ▼ para ajustar la hora de Wake, y oprima NEXT
- 5 Oprima ▲ / ▼ para ajustar la temperatura de Wake, y oprima NEXT
- 6 Repita los pasos 4-5 para fijar los períodos Leave/Return/Sleep
- 7 Repita los pasos 4-6 para fijar los períodos para otros días
- 8 Oprima DONE para salir

### Para anular el programa de horarios

- Oprima ▲ / ▼ para cambiar temp. para este período
- Oprima HOLD, ▲ / ▼ para cambiar temp. para todos los períodos
- Oprima RUN SCHEDULE o CANCEL para seguir con el horario